

# PFAFF

## QUILTJACKET

Size as desired

### You need:

- 2.5 m (3 yds) Green silk fabric
- 1.45 m (1 2/3 yds) Beige fabric for lining
- 0.6 m (2/3 yds) Fusible interfacing
- 2.0 m (2 1/4 yds) Batting
- Beige zipper, 45 cm (18")
- 2 Black press fasteners
- Matching sewing thread in green and beige
- Machine embroidery thread in green
- Bobbin thread
- Tear-away stabilizer
- Free-motion Quilt Foot
- Embroidery needle
- Pfaff creative smart card 338, "Quilt Splendor"
- Burda pattern 8905, view A

## 1 Paper pattern

Cut out all the pattern pieces required for the jacket, view A (no pockets) from Burda pattern 8905. Shorten the front and back yoke by 8 cm (3 1/4"), and lengthen the front and back pieces by 8 cm (3 1/4"). Make one piece of the two back pieces by placing the pattern piece on the fold.

## 2 Cutting

**Note:** Seam allowance is not included on the pattern pieces; please add the seam allowance to the following pattern pieces when you cut out the green silk. Do not add the seam allowance to the batting pieces.

### In the green silk fabric and batting cut:

- 1 – Back yoke
- 2 – Front yoke
- 1 – Upper collar (Cut only in green silk fabric)
- 1 – Under collar
- 1 – Waistband (For batting – cut in half lengthwise)
- 2 – Wristband (For batting – cut in half lengthwise)

Cut out the following pieces from the green silk fabric and batting for quilting:

- 1 – 45 x 60 cm (18" x 24") for the back
- 2 – 30 x 55 cm (12" x 21 2/3") for the centre front
- 2 – 35 x 55 cm (14" x 21 2/3") for the side front
- 2 – 40 x 65 cm (15 3/4" x 26") for the upper sleeve
- 2 – 30 x 65 cm (12" x 26") for the under sleeve

### In green silk fabric and interfacing cut:

- 2 – Front facing

Cut out all lining pieces, following pattern instruction. Note our pattern changes.

## 3 Embroidering

Embroider the green silk fabric.

- Mark the placement for the embroideries on the green silk fabric pieces (Back, centre front, side front, upper sleeve, under sleeve) as shown in the layout diagram.

- Insert creative smart card 338 "Quilt Splendor" in your Pfaff creative 2134 and select design # 13.
- Hoop the fabric with batting and tear-away stabilizer. Thread your Pfaff 2134 with green embroidery thread and bobbin thread in the bobbin and embroider the designs. Remove the tear-away stabilizer from the embellished green silk fabric/batting.

Cut out the pattern pieces. Remember to add the seam allowance.

## 4 Free-motion stippling

Quilt the yokes, collar, waistband and wristband with free motion stippling.

- Place the front and back yokes on batting.
- Place the upper and under collar right sides together and sew the edges and the outer seam together with a straight stitch. Trim seam allowance and turn right side out. Press. Place batting in between.
- Fold the waistband lengthwise right sides together and sew the short edges together with a straight stitch. Turn right side out. Press. Place batting in between.
- Fold the wristband lengthwise, right sides together and sew the short edges together with a straight stitch. Turn right side out. Press. Place batting in between.
- Attach the Free-motion quilt foot and set up your Pfaff 2134 for free-motion stippling. Stipple stitch the yokes, collar, waistband and wristband using the green embroidery thread in the top and in the bobbin.

## 5 Sewing

Sew the jacket and lining following the pattern instruction.

