

## **embroidered Heart-shaped cushion**

**Size 26 cm x 21 cm (10 1/4" x 8 3/8")**

**The cushion is made with the Pfaff creative 2144**

### **You need**

60 cm x 45 cm (24" x 18") orange silk fabric  
Sewing thread matching the fabric  
2 color shades of pink embroidery thread, 40 wt.  
Bobbin thread for embroidery  
Tear away stabilizer  
Fabric marker  
Fiberfill  
Pfaff creative card 309, "Flowers", embroidery design no. 10

Seam allowance is included with 1cm (3/8") in the pattern measurements for the cushion.

### **1 Paper pattern**

You'll find the pattern pieces and diagram for hoop placement on the embroidered fabric in the .pdf file to download. Print them out in Adobe Acrobat and tape them together to make a full sized pattern

### **2 cutting**

Orange:

Front, cut 1. Please note: You have to embroider the fabric first and then cut out the piece exactly.

Back, cut 1

### **3 embroidering**

Use the fabric marker to draw the heart outline on the fabric. Cut out the heart shape roughly, leaving approx. 20 cm (8") fabric around all edges so that it can be hooped easily.

Make a template for the embroidery pattern. Mark outer placement lines. (In the download you'll find a full-sized pattern to trace) Pin the template to the fabric for the first embroidery design

(see pattern placement diagram). Hoop the fabric and embroidery stabilizer. Adjust the hoop position until the needle is positioned exactly at the \_center point. With the reference cross, the embroidery design can be positioned easily. Stitch the first embroidery design. Rehoop the fabric and stitch the remaining designs in the same manner. Remove the embroidery stabilizer. Cut out the heart shape exactly, adding seam allowances.

### **4 finishing**

Pin the front and the back pieces together. Rethread your Pfaff creative 2144 with regular sewing thread that matches the fabric both on top and in the bobbin. Select straight stitch.

Change to presser foot 0A and engage the IDT. Sew together along all edges, leaving approx.

8 cm (3 1/4") open for turning. Trim seam allowances. Turn right side out. Fill with fiberfill.

Sew the open seam section closed.



