

## creative™ 3.0

### Dress - Tips and Hints

#### Shoulder

Start by drawing the shoulder part of your dress pattern on the fabric with a fabric marker. Embroider as many designs as will fit on the piece.

Sew three lines of decorative stitches on each shoulder piece. We used stitches 3.3.12 and 4.1.24.

**Tip:** When sewing decorative stitches, use a thread in a lighter color to increase the contrast.

Once you have sewn and embroidered, cut out the pattern piece.



#### Lower part of the dress

The embellishment on the lower part of the dress includes embroidery, lace and decorative stitches.

Measure the width of the pattern piece to determine the amount of lace that you will need. Embroider built-in lace design, number 7, on water soluble stabilizer using the creative™ Endless Hoop II (820893096) or Grand Endless Hoop (820987096). If you don't have an endless hoop, use the Basic Precise Positioning feature to match up your designs. Read more about the feature in your User's Guide.

Embroider design 5 directly on the fabric, approximately two inches above the finished hemline, using an Endless Hoop (or Basic Precise Positioning feature).

Choose a decorative stitch to further embellish the lower part of the dress. We used stitch 4.1.24.

Place the lace on the decorated fabric. Baste in place then sew the entire lower band to the rest of the dress.



3.3.12



4.1.24

